

# New Printy/Ideal Pad Change with New Ink Catridge



1. Press Down to Lock



2. Insert the New Pad



3. Release the Lock



# New Printy/Ideal Pad Change with New Ink Catridge



1. Press Down to Lock



2. Insert the New Pad



3. Release the Lock



# New Printy/Ideal Pad Change with New Ink Catridge



1. Press Down to Lock




2. Insert the New Pad




3. Release the Lock




# Old Style Stamp Pad Change with New Style Ink Cartridge




1. Press Down to Lock



2. Push Button to Release Ink Cartridge




3. Insert the New Pad




4. Push until Wings Snap Off


# Old Style Stamp Pad Change with New Style Ink Cartridge




1. Press Down to Lock



2. Push Button to Release Ink Cartridge




3. Insert the New Pad




4. Push until Wings Snap Off


# Old Style Stamp Pad Change with New Style Ink Cartridge




1. Press Down to Lock



2. Push Button to Release Ink Cartridge



3. Insert the New Pad



4. Push until Wings Snap Off